

## Floor Mount Articulating Stanchion

The articulating stanchion is an easy to use passenger assist, that provides passengers with a grab handle in the event of a sudden stop, while maintaining current seating layouts and design.



### Instructions for Use:

1. Pull and hold the yellow release knob located under the seat.
2. Lift the seat into the upright position, and release the knob to lock in place.
3. Step on the foot pedal lock release mechanism located on the floor at the bottom of the stanchion.
4. Begin the rotation of the stanchion inward, release the pedal and continue to rotate toward the seat bottom. You will hear an audible click when the stanchion is stored in the locked position.

**Now additional space is created to accommodate a mobility aid device in the A.D.A. area.**

5. Once the A.D.A. area is no longer needed, step on the foot pedal lock release mechanism located on the floor at the bottom of the stanchion.
6. Rotate the pole outwards, release the pedal and continue to rotate away from the seat bottom until stored in the locked position (audible click).
7. Pull and hold the yellow release knob, located under the seat, and pull down the seat to the use position.

**Now the system is fully deployed and ready to use by able body patrons.**